



WINTER TRAIL ETIQUETTE



THINK BEFORE YOU SINK



- Please use snowshoes, skis, or fat tire bikes. **Fat tires should be at least 3.5" wide.**
- You should be floating on the groomed surface of the trail.



- Leaving behind tracks or prints greater than 1" deep.
- When you break the groomed snow surface, it degrades the trail for everyone.



2-8 PSI *(depending on conditions)*
on groomed surfaces.

TRAIL COURTESY



YIELD
TO



THINK BEFORE YOU SINK



If you're leaving a rut, try letting air out of your tires. 2-8 PSI will treat you and the trails well.



If you're leaving foot prints, try on some snowshoes.

HELPING EVERYONE ENJOY THE TRAIL.



VERMONT MOUNTAIN BIKE ASSOC.
SINCE 1997

vmba.org